



1. PRE-ASSEMBLY ITEMS (1) - (6) AS SHOWN.
2. INSERT WEDGE ASSY (5,6) INTO BASE (7).
3. PRESS TUBE (8) AND GUIDE (9) INTO BASE USING FIXTURE PROVIDED.
4. ATTACH LIFT ARM ASSY (1,2) TO WEDGE ASSY (5,6) WITH SCREW (10).
5. INSERT ORING (11) INTO BASE (7) AS SHOWN.
6. ATTACH ORING (13) TO FLOAT (12).