

D-TYPE MICRO MATIC KEG COUPLER SERVICE TIPS SERVICE KIT # 35781512



1. Unclip handle hinge pin (#35654034) & slide off. Slide handle (#35654022) back to remove.



2. Remove the white gasket probe seal (#35122164) with O-ring pick to allow removal of probe.
Push probe from gasket end out of the top of the keg coupler body.



3. There are 2x O-rings (#35000052) in the body of the keg coupler. Remove these with your O-ring pick & replace. Use small amount Kluber grease on O rings.



4. The last seal to change on the D-Type keg coupler is the base seal (#79700996) on the bottom of the coupler. The flat face of the seal to be located against the body



5. Re-assemble - Insert probe into the keg body (gasket end first). Once probe is in the keg coupler body, fit a new "white" gasket probe seal (#35122164).



6. If the "white" gasket probe seal is fitted before putting the probe into the coupler, it will NOT go back together.



7. Replace the probe by inserting the threaded end of the probe into the body of the coupler & slide in as shown above.



8.Push in the hinge pin & fasten in place. You have now serviced your **D-Style Keg Coupler**.



D Type Service Kit - 35781512 **Kluber Grease** - 47517171 **O-Ring Pick Set** - 00000090

Page 33